


INSTALLATION AND SERVICE MANUAL




For installation of Tango 2,12 cylindrical and square Wall up-down light.
Model. UTA-30384, UTA-30386-30387 and UTA-30734, UTA-30736-30737.

Product drawing (dimensions)




UTA-30384, UTA-30386-30387




UTA-30734, UTA-30736-30737

SUITABLE FOR WET LOCATIONS




TOOL




MOUNTING DETAIL

NOTE


Mounts over
a 3"Octagonal
Junction box.



①



②



③

Notice to installer :

- 1.WIRING INSTRUCTIONS** Warning : RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.
- 2.This fixture has a VOLTAGE SPECIFIC BALLAST,Check that the supply voltage is the same as the installed ballast voltage.**

Ligman Lighting USA

7144 NW Progress Court, Hillsboro
Oregon, 97124, USA
Tel : 503 645 0500 | Fax : 503 645 8100

www.ligmanlightingusa.com


UTA-30384/13/06/14/REV.1
1/2



FM-TS-13/25-05-2007-REV.2


Center the Back Plate over the J Box and Secure the back plate to the wall

4




Ensure watertight seal using UL approved silicone based sealant.

5




Connect Power and Ground Wire.


6




7




8




9



10



11



12

