


INSTALLATION AND SERVICE MANUAL

LIGMAN
LIGHTING USA


For installation of Sandy Small Surface Wall Light LED .
Model.USA-31471,31481,31491,31501,31521

Product drawing (dimensions)


SUITABLE FOR WET LOCATIONS




USA-31471




USA-31481






USA-31491



USA-31501



USA-31521





MOUNTING DETAIL




ISO VIEW

NOTE Junction box.


1



2




3




4

Connect Power and Ground Wire.


5



Ensure watertight seal
using UL approved silicone based sealant.



6



7

Notice to installer :

- 1.WIRING INSTRUCTIONS** Warning : RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.
- 2.This fixture has a VOLTAGE SPECIFIC BALLAST,Check that the supply voltage is the same as the installed ballast voltage.**

Ligman Lighting USA

7144 NE Progress Court, Hillsboro
Oregon, 97124, USA
Tel : 503 645 0500 | Fax : 503 645 8100

www.ligmanlightingusa.com

USA-31471 19/06/24 REV.1
1/1

FM-TS-13-1/13-05-2563/Rev.6