


INSTALLATION AND SERVICE MANUAL

LIGMAN
LIGHTING USA


For installation of Itac Surface Mounted Luminaires LEDs
Model. UIT-31961 , UIT-31971

PRODUCT DRAWING (DIMENSIONS)


SUITABLE FOR WET LOCATIONS



UIT-31961




UIT-31971




MOUNTING DETAIL


NOTE Mounts over
Junction box.




1



2



3



4

Notice to installer :

- 1.WIRING INSTRUCTIONS** Warning : RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.
- 2.This fixture has a VOLTAGE SPECIFIC BALLAST,Check that the supply voltage is the same as the installed ballast voltage.**

Ligman Lighting USA

7144 NE Progress Court, Hillsboro
Oregon, 97124, USA
Tel : 503 645 0500 | Fax : 503 645 8100

www.ligmanlightingusa.com

UIT-31961 08/11/24 REV.2
1/2

FM-TS-13-1/13-05-2563/Rev.6

