


INSTALLATION AND SERVICE MANUAL


LIGMAN
NORTH AMERICA

For Installation of Gini 1, 2 Downlight and Up/Downlight Wall Surface Luminaire LED.
Model. UGN-30041, UGN-30051, UGN-30061, UGN-30071, UGN-30081 and UGN-30091


PRODUCT DRAWING (DIMENSIONS)




SUITABLE FOR WET LOCATIONS



NOTE Mounts over Junction box.



①




②


Remove The Fixture part

Position the gasket and mounting plate over the Junction Box and Secure to the wall


③



④




⑤




Connect Power and Ground Wire.


⑥



⑦



⑧



Notice to installer :

WIRING INSTRUCTIONS Warning : RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.

Ligman Lighting USA

7144 NE Progress Court, Hillsboro
Oregon, 97124, USA
Tel : 503 645 0500 | Fax : 503 645 8100

www.ligmanlightingusa.com

UGN-30041 09/02/26 REV.1
1/1

FM-TS-13-2/21-03-2568/Rev.5