



# INSTALLATION AND SERVICE MANUAL

For installation of Gantry Arm Wall Mount For Steamer.  
Model. A31291

## Product drawing (dimensions) SUITABLE FOR WET LOCATIONS




**NOTE**  
Mounts over  
a 3" Octagonal  
Junction box.





1

2



3

4



### Notice to installer :


1. **WIRING INSTRUCTIONS Warning** : RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.
2. This fixture has a **VOLTAGE SPECIFIC BALLAST**, Check that the supply voltage is the same as the installed ballast voltage.

**Ligman Lighting USA**


7144 NE Progress Court, Hillsboro  
Oregon, 97124, USA  
Tel : 503 645 0500 | Fax : 503 645 8100

[www.ligmanlightingusa.com](http://www.ligmanlightingusa.com)

5



6



7

