


INSTALLATION AND SERVICE MANUAL

LIGMAN
LIGHTING USA

For Installation of Augusta 1,2,3 Wall Light LED.
Model. UAUG-30001, UAUG-30011 and UAUG-30021


Product drawing (dimensions)

SUITABLE FOR WET LOCATIONS




MOUNTING DETAIL

UAUG-30001




MOUNTING DETAIL

UAUG-30011




MOUNTING DETAIL


UAUG-30021



1




2



3

Connect power
and Ground wire



4

Notice to installer :

- 1.WIRING INSTRUCTIONS** Warning : RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.
- 2.This fixture has a VOLTAGE SPECIFIC BALLAST,**Check that the supply voltage is the same as the installed ballast voltage.

Ligman Lighting USA

7144 NE Progress Court, Hillsboro
Oregon, 97124, USA
Tel : 503 645 0500 | Fax : 503 645 8100