


# INSTALLATION AND SERVICE MANUAL




For installation of Light linear PT wall light LED.  
Model. ULI-30011 and ULI-30012.

## Product drawing (dimensions)





## SUITABLE FOR WET LOCATIONS





## NOTE

Mounts over a 3" or 4" Octagonal Junction box.

1






Using Proper Mounting Screws,  
Secure the back plate to the wall



Connect Power and Ground Wire

5



## Notice to installer :

- 1. WIRING INSTRUCTIONS** Warning : RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.
- 2. This fixture has a VOLTAGE SPECIFIC BALLAST, Check that the supply voltage is the same as the installed ballast voltage.**

Ligman Lighting USA

7144 NW Progress Court, Hillsboro  
Oregon, 97124, USA  
Tel : 503 645 0500 | Fax : 503 645 8100

[www.ligmanlightingusa.com](http://www.ligmanlightingusa.com)

ULI-30011 05/10/15/REV.0

1/1



FM-TS-13/25-05-2007-REV.2